



NEW YORK STATE DEPARTMENT OF TRANSPORTATION
MATERIALS BUREAU ALBANY, NY 12232-0861


Test Method No.: NY 703-20 F

TEST METHOD

Issue Date: 12/01/2013
Subject Code: 7.42-5

SUBJECT: MOISTURE CONTENT OF LIGHTWEIGHT COARSE AGGREGATE

APPROVED:


Donald A. Streeter, P.E., Field Engineering 1, Materials Bureau

Supersedes:
Dated:

SCOPE:

This method describes the procedures for determining the total, absorbed, and surface (also known as free) moisture of Lightweight Coarse Aggregate to be used for lightweight Portland cement concrete.

EQUIPMENT:

1. Sampling container: Non-absorbent, sealable, bag or tub with a capacity sufficient for holding approximately 3000 grams of lightweight coarse aggregate.
2. Scoop, shovel, or large spoon.
3. Sheet of non-absorbent cloth, canvas or polyethylene (approximate size, 24" (600 mm) x 24" (600 mm)).
4. Drying apparatus: A ventilated oven capable of maintaining temperature of $230 \pm 9^{\circ}\text{F}$ ($110 \pm 5^{\circ}\text{C}$) for 24 hours. In cases where the aggregate is not altered by overheating, other sources of heat, such as electric or gas hotplates, electric heat lamps, or a ventilated electric microwave oven may be used.
5. Disposable paper towels, or clean, absorbent cloth towels.
6. Heat resistant pans: With sufficient capacity to hold a minimum of 500 grams of coarse aggregate in an oven or on a hot plate at the specified temperature. If a microwave oven is used for drying, the container shall be non-metallic.

SAMPLING:

- For determination of surface moisture content at the Portland cement batching facility (for adjustments to target batch weights) prior to batching:

After the required soaking and draining of the stockpiles has been completed, obtain a representative sample from the stockpile or plant storage bin in accordance with sampling procedures described in Materials Method (MM) 9.1, Plant Inspection of Portland Cement Concrete. Obtain a minimum sample size of 3000 grams. Immediately upon obtaining the composite sample, place it in a non-absorbent container to prevent loss of moisture prior to testing.

TESTING:

Reduce the sample, by quartering, into four sub-samples of approximately 750 grams each.

Immediately determine the initial weight of one sub-sample by weighing to the nearest 0.1 grams. This sub-sample will be known as "Sample #1." Record the initial weight of Sample #1 as W_T . Place Sample #1 in the drying apparatus. Dry Sample #1 to a constant weight, so that the loss in weight between subsequent measurements does not change by more than 0.1% of the original weight.

After drying, allow Sample #1 to cool sufficiently, so as to not damage the weighing equipment. Measure the weight of Sample #1 to the nearest 0.1 grams and record the weight as W_{OD} . The mathematical difference between the initial weight (W_T) and the oven dried weight (W_{OD}) represents the "total" (absorbed and surface) moisture.

Calculate the "% Total Moisture" content of Sample #1 (expressed as a percent of the oven dried weight) as follows:

$$\% \text{ Total Moisture: } (M_T) = 100 \times (W_T - W_{OD}) / W_{OD}$$

Place another sub-sample, which will be known as "Sample #2," on a 2 - 3 foot long sheet of clean, dry towel. Spread the sample uniformly across the towel while patting the sample with another towel. Continue patting and spreading the sample, replacing the towel whenever it becomes too damp or dirty to absorb moisture. This process should be conducted as quickly and carefully as possible. Repeat the patting and spreading of the sample until no further moisture or "sheen" appears on the sample. Immediately weigh Sample #2 to the nearest 0.1 gram. Since the surface moisture has been removed, this weight represents *only* the moisture that has absorbed into the sample. Record this weight as W_{TD} .

Place Sample #2 in the drying apparatus. Dry Sample #2 to a constant weight so that the loss in weight between subsequent measurements does not change by more than 0.1% of the original weight. Measure the weight of Sample #2 to the nearest 0.1 grams and record the weight as W_{2OD} .

Calculate the "% Absorbed Moisture" content of Sample #2 as follows:

$$\% \text{ Absorbed Moisture: } (M_A) = 100 \times (W_{TD} - W_{2OD}) / W_{2OD}$$

Calculate the "% Surface Moisture" content as follows:

$$\% \text{ Surface Moisture: } (M_S) = \text{Total Moisture } (M_T) - \text{Absorbed Moisture } (M_A)$$

$$\text{Example: } M_S = M_T - M_A$$

$$M_S = 20.3\% - 16.4\% = 3.9\% \text{ Surface Moisture.}$$

Report the Surface Moisture to the nearest 0.1%. This value will be used to adjust the pre-programmed target weight of the lightweight coarse aggregate and water in the batching facility's automated batching system. Consult MM 9.1 or MM 27 for more information on automated batching systems.

Use the following worksheet for the necessary calculations:

LIGHTWEIGHT AGGREGATE MOISTURE WORKSHEET

Date: _____ Facility#: _____ Facility Name: _____

Time: _____ Inspector: _____

Sample 1Initial weight (gm): _____ (W_T)Oven dry weight (gm): _____ (W_{OD})Total Moisture: _____ % (M_T)

$$M_T = 100 \frac{(W_T - W_{OD})}{W_{OD}}$$

Sample 2Towel dry weight (gm): _____ (W_{TD})Second Oven dry weight (gm): _____ (W_{2OD})Absorbed Moisture: _____ % (M_A)

$$M_A = 100 \frac{(W_{TD} - W_{2OD})}{W_{2OD}}$$

If the supplier submits a mix design using *dry* LWA, use the following calculation to obtain the proper SSD weight when inputting the LWA design weight into the automation system's mix design entry screen:

SSD weight for Mix Design:

_____ lbs (dry wt. from supplier) X 1. _____ % (M_A)

= _____ lbs. (SSD)



Use this number to enter the LW Aggregate's SSD weight on the batching system's mix design screen.

Example: 186 # (dry weight from supplier) X 1.23% (Absorbed Moisture (M_A)) = 229 #

(SSD weight for mix design)

Surface Moisture:

 M_T _____ % - M_A _____ % = M_S _____ %

Use this number to enter the % of surface (or free) moisture in the LWA bin in the automation system's bin moisture screen.