

ITEM 203.0393 01- FURNISH, MAINTAIN AND OPERATE CERTIFIED TRUCK SCALE(S)

DESCRIPTION

This work shall consist of furnishing, maintaining and operating Certified Truck Scale(s) in accordance with the contract documents and as directed by the Engineer.

MATERIALS

Provide certified scale(s) capable of weighing fully loaded trucks of the type used to transport tire shreds. Certified Public Scale(s) or scale(s) furnished to the project may be utilized. All scale(s) shall be certified and bear the unexpired seal of the appropriate Sealer of Weight and Measures. Storage, placement and handling of the scales is the Contractor's responsibility.

CONSTRUCTION DETAILS

1. Certified Public Scales
Designate location of scale(s) to the Engineer. Do not utilize scale(s) until authorized to do so, in writing, by the Engineer. Weigh each truck used and provide the tare weight to the Engineer or his designated representative. Weigh each truck fully loaded, and provide a ticket for each truck load which indicates, as a minimum, scale identification, date and time, and loaded truck weight.

2. Scales Furnished to Project
Weigh each truck to be used to determine tare weight in the presence of the Engineer or his representative. Weigh each fully loaded truck in the presence of the Engineer or his representative to determine the weight of the tire shreds. Remove scales from the project site which are damaged or non-working.

METHOD OF MEASUREMENT

This work will be measured on a lump sum basis.

BASIS OF PAYMENT

The lump sum price bid shall include the cost of furnishing all labor, materials, and equipment necessary to satisfactorily complete the work.